

SHIFT BOOT COLLAR INSTALLATION GUIDE



INCLUDED

- Shift Boot Collar (NTA)
- Zip Tie

TOOLS

- Allen Key Set
- Wire Cutter

READ BEFORE INSTALLATION

If you have a shift knob with no engraving, follow the **INSTALLATION GUIDE - NO ENGRAVING** steps below. If you have a shift knob with engraving, follow the **INSTALLATION GUIDE - ENGRAVING** steps below.

INSTALLATION GUIDE - NO ENGRAVING

- 1 Unscrew and set your Raceseng shift knob.
- 2 Place your Shift Boot Collar onto the adapter and orient the collar to your preference.
- 3 Tighten your shift knob back onto the adapter.
- 4 Enjoy the drive!

INSTALLATION GUIDE - ENGRAVING

- 1 Unscrew and set your Raceseng shift knob.
- 2 Remove the shift boot assembly from the center console to expose the set screws on the adapter. Cut the zip tie holding the shift boot to the adapter.
- 3 Install the Shift Boot Collar, then the shift knob on the adapter and orienting the collar and engraving. Remember, the engraving is going to land wherever the fully tightened assembly stops it.
- 4 Loosen the adapter set screws.
- 5 Orient the shift knob engraving to your preference.
- 6 Tighten the set screws on the adapter.
- 7 Loosen and remove the shift knob and shift knob collar.
- 8 Attach the shift boot to the adapter using the zip tie and trim the excess with a wire cutter. Reinstall the shift boot assembly into the center console.
- 9 Reinstall the Shift Boot Collar and shift knob.
- 10 Enjoy the drive!

NEED HELP?
tech@raceseng.com

