

## SHIFT BOOT COLLAR \ RETAINER INSTALLATION GUIDE



### INCLUDED

- Shift Boot Collar \ Retainer (TA)
- Zip Tie

### TOOLS

- Allen Key Set
- Wire Cutter
- 15mm Wrench

### READ BEFORE INSTALLATION

- If you already installed a shift knob with or without an engraving, proceed to **INSTALLATION GUIDE - REFRESH.**
- If you are removing either the OEM shift knob or someone else, proceed to **INSTALLATION GUIDE - FRESH.**

### INSTALLATION GUIDE - REFRESH

- 1 Unscrew and set your Raceseng shift knob aside, in a safe spot.
- 2 Remove the threaded adapter with the 15mm wrench.
- 3 Remove your shift boot, and flip inside-out.
- 4 Place your Shift Boot Collar \ Retainer (*boot retainer end first*) into the big end of the now reversed shift boot, allowing it to rest at the small end of your shift boot.
- 5 Use the included Zip Tie to secure the small end of the shift boot onto the boot retainer section of the collar. Flip the boot to right-side-out. Once you're satisfied with the boot placement, tighten the Zip-Tie as best as you can and trim the excess away with the wire cutters.
- 6 Reinstall your shift boot assembly with the Shift Boot Collar \ Retainer placed as low as possible onto the shift arm.
- 7 Reinstall the threaded adapter and tighten into place with the 15mm wrench.
- 8 Reinstall your Raceseng Shift Knob, orient the engraving as needed with a 4mm Allen key on the M6 flat head cap screw. This won't be necessary if you went with *no engraving*.
- 9 Rotate the Shift Boot Collar \ Retainer to face the desired direction and lift into the bottom of the shift knob. Rotate before insertion; the interference fitment makes it tough to twist once it is fully seated.
- 10 Enjoy the drive!

### INSTALLATION GUIDE - FRESH

- 1 Unscrew your OEM shift knob and set aside. Depending on your car, some shift boots need to be separated from the knob prior to removal.
- 2 Remove your shift boot, and flip inside-out.
- 3 Place your Shift Boot Collar \ Retainer (*boot retainer end first*) into the big end of the now reversed shift boot, allowing it to rest at the small end of your shift boot.
- 4 Use the included Zip Tie to secure the small end of the shift boot onto the boot retainer section of the collar. Flip the boot to right-side-out. Once you're satisfied with the boot placement, tighten the Zip-Tie as best as you can and trim the excess away with the wire cutters.
- 5 Install your shift boot assembly with the Shift Boot Collar \ Retainer placed as low as possible onto the shift arm.
- 6 Install the threaded adapter and tighten into place with the 15mm wrench.
- 7 Install your Raceseng Shift Knob. If you purchased an engraving, the orientation of the knob is adjusted using a 4mm Allen Key on the M6 flat head cap screw located at the top of the adapter. It adjusts where the knob stops as you screw the knob into place.
- 8 Rotate the Shift Boot Collar \ Retainer to face the desired direction and lift into the bottom of the shift knob. Rotate before insertion; the interference fitment makes it tough to twist once it is fully seated.

**NEED HELP?**  
tech@raceseng.com

