



SHIFT BOOT COLLAR INSTALLATION GUIDE



INCLUDED

- Shift Boot Collar (NTA)
- Zip Tie

TOOLS

- Allen Key Set
- Wire Cutter

READ BEFORE INSTALLATION

- If you already installed a Raceseng shift knob with or without an engraving, proceed to **INSTALLATION GUIDE - REFRESH**.
- If you are removing either the OEM shift knob or someone else, proceed to **INSTALLATION GUIDE - FRESH**.

INSTALLATION GUIDE - REFRESH

- 1 Unscrew and set your Raceseng shift knob aside, in a safe spot.

1A If you have a *no engraving* knob, install the collar and orient as desired; reinstall the knob and skip to **step 8**.
- 2 Lift and remove the shift boot away from the non-threaded adapter. If it is necessary to cut the Zip-Tie, we've provided another.
- 3 Install your Shift Boot Collar (NTA) and Raceseng shift knob. Alignment isn't important at this point.
- 4 Loosen the set screws that secure the non-threaded adapter to the shift arm.
- 5 Rotate the engraved shift knob and non-threaded adapter together until the engraving is where you want it, then re-tighten the set screws to secure everything to the shift arm.
- 6 Loosen and remove the shift knob and collar and set aside to reinstall the shift boot.
- 7 Reinstall the Shift Boot Collar and shift knob, orienting the engraving and collar and tighten as desired.
- 8 Enjoy the drive!

INSTALLATION GUIDE - FRESH

- 1 Remove your OEM shift knob and set aside. Depending on your car, some shift boots need to be separated from the knob, so the boot and knob may need to be removed together.
- 2 Separate your shift boot from the OEM shift knob, and flip the boot inside-out.
- 3 Insert the boot over the shift arm, small side first. The boot bezel should be oriented correctly, but **NOT** installed yet.
- 4 Assemble your Shift Boot Collar (NTA), the non-threaded adapter and the new Raceseng Shift Knob together.
- 5 Place the shift knob assembly onto the shift arm and orient the engraving slightly to the right of your liking. Doing this gives enough space so you can further tighten the shift knob **AFTER** the next step.
- 6 Tighten the set screws to secure the non-threaded adapter onto the shift arm.
- 7 Tighten the new Raceseng Shift Knob into place to make sure you're satisfied with the final orientation; if not, simply loosen the set screws from Step 6, re-orient and re-tighten.
- 8 Loosen and remove the Raceseng Shift Knob and Shift Boot Collar.
- 9 Lift the shift boot up until the small end is covering the non-threaded adapter and use the included Zip-Tie to secure the small end of the boot to the retainer area of the adapter.
- 10 Reinstall your shift boot into its factory location.
- 11 Reinstall the Shift Boot Collar and shift knob, orienting the engraving and collar and tighten as desired.
- 12 Enjoy the drive!

NEED HELP?
tech@raceseng.com

